



6067 Schumacher Dr West Chester, OH 45069 Phone: (513) 874-5958 Fax: (513) 874-1162

AM28, A5000, & Master J Training Instructions

This training checklist is intended to ensure that you, the customer, have been sufficiently instructed on the proper usage, maintenance, and repair (where applicable) of your new Corghi tire changer. If you are unsatisfied with the training you received, please contact Corghi USA and ask to speak to the Sales Manager in charge of your region.

Thank you for choosing Corghi!

Model: _____

Serial Number: _____

This form must be filled out completely with signatures and returned to Corghi USA

A copy will be mailed to the customer

Please check the appropriate box for each section that you were instructed on.

Standard Procedure:	Initial	Comments:
Proper functions of the pedal assembly, demonstrated two speed motor and explained importance and applications		
Proper functions of the wheel lift		
Proper functions of the locking pistol, additional cones, spacer ring & its applications, procedure to lock rim to turn table to allow for smooth operation		
Procedure for lifting tire & wheel assembly onto turn table & how easily its positioned		
Procedure for breaking upper bead utilizing bead surge feature		
Procedure for breaking lower bead utilizing bead surge feature Explained possibility of bead re-seating & proper steps		
Procedure for demounting upper bead of tire & alternative methods Stiff run-flat tires, pressure release procedure, demounting tire that will not stay in drop center (use of bead clip at 180°)		
Procedure for demounting lower bead		
Procedure for re-mounting new or repaired tires		

Procedure for mounting top/upper bead & methods to do so. No bead clip, white upper roller & one bead clip, white upper roller & two bead clips, importance of slower speed on motor for this portion		
Procedure for releasing pistol & placing it in holding apparatus (one hand on pistol handle, the other on the cone)		
Procedure for removing completed tire & wheel assembly w/ wheel lift		
Proper procedure of use of reverse mount kit (If applicable)		
Proper use of clad wheel adapter (If applicable)		
Proper use of bead blast inflation (If applicable)		
Procedures for proper maintenance. The customer should always refer to the maintenance section of the machine's operators manual and general maintenance section of section of training form		
Where you informed of:		
The Technical Support Line? 1-513-874-5958 Option 2		
A unit failure out of the box? Contact Corghi USA at 1-800-260-0968 Option 2 Immediately.		
A missing part/accessory? Contact Corghi USA at 1-800-260-0968 Option 2 Immediately.		
The warranty period for this unit along with a printed copy?		

General Machine Maintenance for AM28, A5000, & Master J

Always refer to your operator's manual or contact Corghi USA service department for any technical questions.

General maintenance should be performed at least monthly or more frequently based on usage.

- Under NO circumstance is your machine to be pressure washed. To clean your machine, only use mild detergents sprayed directly onto a rag.
- Keep tabletop free of any debris
- Inspect air lines and gauges for kinks and cracks
- Ensure automatic oiler bowl is full and adjusted properly (Refer to operator's manual for proper procedure). Use non-detergent SAE20 air tool oil.
- Use WD40 or equivalent (DO NOT use white lithium grease) to lube the following: exposed cylinder shafts, horizontal MD head shaft, wheel lift guide shaft, and threaded screw oil pad
- Grease the following using an all-purpose shop grease: front and rear vertical guide rails, bead breaker vertical guide shaft, and the upper bead breaker locking handle. DO NOT grease the vertical screw shaft!
- Ensure Mount/Demount fingers are at the 6 & 12 o'clock positions when retracted.
- Check that the Mount/Demount to wheel distance is between 2mm and 4mm.
- Change MD head inserts when worn flat.
- Ensure proper vertical movement of the MD head by listening for the audible "click" of the brake when activating the head up and down.
- Check that the upper and lower rubber stops for the vertical MD head movement are not cracked.
- Check the bead breakers for excessive play up, down, left, and right. This play should be no more than 5mm at any time.
- Inspect white bead breaker rollers for gouges and cracks. The rollers should also spin freely.
- Inspect the lockdown pistol teeth for any chips or cracks.
- Inspect all cones for any cracks or gouges. CAUTION: Using a damaged component associated with the lockdown system may cause injury. Always inspect the pistol, cones, spacers, and any other components for damage prior to usage.

General Terms, Disclaimer & Limitation on Liability

Corghi USA expressly warrants its products will be free from defects in material and/or workmanship for the time period specified. Corghi USA must be informed in writing within 7 days after discovery of a defect. Corghi USA reserves the right to repair or replace a product at our discretion. Consumable products and accessories such as but not limited to; plastic protection parts, bead breaker pads, inflation hoses, and rollers, are not covered under this warranty. This warranty does not cover any damage resulting from abuse or failure to perform any necessary maintenance (i.e. damage due to or resulting from, faulty installation, neglect, misuse, improper electrical connections or electrical surges, problems resulting from excessive water, contaminated air system, or pollutant of any nature, fire or freight damage).

Corghi USA's agreement to repair machines is expressly in lieu of all other warranties, express, implies or statutory, including any warranties for merchantability and fitness for a particular purpose. Corghi USA maximum liability shall be limited to the cost of the machine. In no event shall Corghi USA be responsible for owner's lost profits, goodwill or other incidental or consequential damages. Freight damage to equipment or accessories shipped directly from Corghi USA must be communicated directly to Corghi USA within 24 hours of receipt. Corghi USA is not responsible for damaged equipment or accessories that have not been reported within 24 hours of receipt. Corghi USA is not responsible for damaged equipment or accessories shipped directly from other distributors. Freight claims are to be made directly with those distributors.

AM28, A5000, & Master J 2 years parts and 1 year labor

NOTE: Rubber Pads, air lines, gauges, mount/demount heads, and swabs - 90-day warranty

Time spent on installation: _____ Customer Initial: _____

Time spent on training: _____ Customer Initial: _____

Additional Notes/Comments: _____

Customer Information: Email: _____

Business Name	Street Address	City	State	Zip Code
Customer Printed Name	Customer Signature	Phone Number	Date	

Please check this box if you are declining Installation and/or training from Corghi USA.

Reason for Declining: _____

☐

For Corghi USA representative use only.

Work Order/Claim Number	Service Center Name/ Account Number
Instructor Printed Name	Instructor Signature
Sales Representative Printed Name	Sales Representative Signature