



6067 Schumacher Dr West Chester, OH 45069 Phone: (513) 874-5958 Fax: (513) 874-1162

## Monster AGTT Training Instructions

This training checklist is intended to ensure that you, the customer, have been sufficiently instructed on the proper usage, maintenance, and repair (where applicable) of your new Corghi tire changer. If you are unsatisfied with the training you received, please contact Corghi USA and ask to speak to the Sales Manager in charge of your region.

**Thank you for choosing Corghi!**

**Serial Number:** \_\_\_\_\_

**This form must be filled out completely with signatures and returned to Corghi USA  
A copy will be mailed to the customer**

Please check the appropriate box for each section that you were instructed on.

<b>Standard Procedure:</b>	<b>Initial</b>	<b>Comments:</b>
Check for correct power requirements, 200 Vac, 208 & 230 can be used		
Adjust tension on support feet		
Identification of main operating components – Bead breaker arm, jaws, carriage, control box, laser		
Controls on hand controller, joysticks, rocker switches, rotation speed switch, rabbit mode, emergency stop button, automatic functions, tire size selection, NOTE: The red and black rotation direction arrows match the arrows indicated on the machine		
Proper use of the finger and bead breaker disk, 3 positions for finger and 2 for disk		
Pump override switch on control cabinet for warming up fluid (pump constantly on) NOTE: Rabbit mode will not work when this is active		
Battery charger & adapter NOTE: Battery will not charge if the braided back up control cable is plugged in		
Two working positions of jaws; closed for center clamping and open for hub-less or closed center wheels		
Optional accessories – Aluminum protection rings, aluminum bead clamp, skidder clamp		
Importance of tire lube		
Importance of keeping tire in the drop-center of the rim, in some cases special tools may be needed such as hydraulic bead breaker tools		
Explained machine maintenance including machine lubrication points, fuse location & machine overload switches. The customer should always		

refer to the maintenance section of the machines operators' manual and the general maintenance section of the training form		
<b>Where you informed of:</b>		
The Technical Support Line? 1-513-874-5958 Option 2		
A unit failure out of the box? <b>Contact Corghi USA at 1-800-260-0968 Option 2 Immediately.</b>		
A missing part/accessory? <b>Contact Corghi USA at 1-800-260-0968 Option 2 Immediately.</b>		
The warranty period for this unit along with a printed copy?		

## General Machine Maintenance for Monster AGTT

Always refer to your operator's manual or contact Corghi USA service department for any technical questions. General maintenance should be performed at least monthly or more frequently based on usage.

- Under NO circumstance is your machine to be pressure washed. To clean your machine, only use mild detergents sprayed directly onto a rag.
- Use WD40 or equivalent (DO NOT use white lithium grease) to lube all hydraulic cylinder shafts (5 total)
- Grease the following using an all purpose shop grease: Bead breaker disk, finger rod joint, slide rail for carriage support (no zurch fitting), main jaw spindle
- Using high pressure loc-cease grease (Corghi part number 1-04666) Grease the following: Bead breaker carriage slide rails and blocks, bead breaker rotation guide, main carriage slide rails and blocks, main support carriage slide rails and blocks, bead breaker arm guide rails NOTE: Use of any lubrication other than the loc-cease or equivalent may cause damage to the machine and void the warranty
- Inspect hydraulic lines and gauges for kinks and cracks
- Check hydraulic fluid level, top off with 32 wt non-foaming

## General Terms, Disclaimer & Limitation on Liability

Corghi USA expressly warrants its products will be free from defects in material and/or workmanship for the time period specified. Corghi USA must be informed in writing within 7 days after discovery of a defect. Corghi USA reserves the right to repair or replace a product at our discretion. Consumable products and accessories such as but not limited to; plastic protection parts, bead breaker pads, inflation hoses, and rollers, are not covered under this warranty. This warranty does not cover any damage resulting from abuse or failure to perform any necessary maintenance (i.e. damage due to or resulting from, faulty installation, neglect, misuse, improper electrical connections or electrical surges, problems resulting from excessive water, contaminated air system, or pollutant of any nature, fire or freight damage).

Corghi USA's agreement to repair machines is expressly in lieu of all other warranties, express, implies or statutory, including any warranties for merchantability and fitness for a particular purpose. Corghi USA maximum liability shall be limited to the cost of the machine. In no event shall Corghi USA be responsible for owner's lost profits, goodwill or other incidental or consequential damages. Corghi USA is not responsible for equipment or accessories damaged in shipment. Freight claims are to be made directly with the carrier. We will be more than happy to assist you with any questions regarding filing claims.

**Monster AGTT 2 years parts and 1 year labor**

**NOTE:** Rubber Pads, air lines, gauges, mount/demount heads, and swabs - 90 day warranty

Time spent on installation: \_\_\_\_\_ Customer Initial: \_\_\_\_\_

Time spent on training: \_\_\_\_\_ Customer Initial: \_\_\_\_\_

Additional Notes/Comments: \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

**Customer Information:**

Business Name	Street Address	City	State	Zip Code
Customer Printed Name	Customer Signature	Phone Number	Date	

Please check this box if you are declining Installation and/or training from Corghi USA.

Reason for Declining: \_\_\_\_\_

**For Corghi USA representative use only**

Work Order/Claim Number	Service Center Name/ Account Number
Instructor Printed Name	Instructor Signature
Sales Representative Printed Name	Sales Representative Signature